



Sandstone and Pre-Cast Concrete

---

## Installation Procedure for Benzini Ornamental Pieces

---

**Benzini products do not come glued together due to their weight and transport requirements. This applies to all Urns, Pedestals, Pillars, Letterboxes, Furniture, and any other two or more piece items.**

### **INSTALLATION**

We recommend that the elements of the ornamental piece be stuck together using a suitable adhesive. This is most important for urns, tables and letterboxes. It is optional for garden benches and pedestals.

We recommend the use of **SIKAflex-11FC** as an adhesive for this application.

Place the item on a solid level surface. It may be necessary to test place each of the elements of the piece you are installing first before applying adhesive to the mating surfaces. When gluing parts together ensure that the surfaces to be glued are free of loose sand or concrete and that the surfaces are dry and clean of oils or detergents.

Working from the bottom most element of the assembly, glue each piece to its mating part until all parts are fixed together. Ensure that the assembly is not bumped or moved once positioning correctly. Use a level to ensure correct installation is achieved. Leave to dry for 24 hours before planting, filling with water or using.

Benzini pots, urns, planters come interior sealed ready for planting or water feature use. It is also recommended to exterior seal to help maintain the sandstone product. See our "Sealing Recommendations" pdf.

### **Important Note:**

After correct installation of a Benzini ornamental piece, it is crucial that children do not hang from or play near to the installation in case one of the components becomes dislodged from the assembly and falls onto a person.

As an extra safety precaution until the adhesive is fully set the area should be barricaded to prevent children entering the installation area.

Children must be supervised when they are near to the ornamental pieces being installed.